


PEAK HOUR ITM SUMMARY

#003 15th St & California Avenue

LOCATION#: 003	QTD PROJ#: 100158	AM PEAK: 745 AM
NORTH / SOUTH: 15th St	DATE: Thursday, September 23, 2010	MD PEAK: 1200 PM
EAST / WEST: California Avenue	VICINITY: San Pablo, CA	PM PEAK: 500 PM



AM COUNT 7:00AM TO 9:00AM MD COUNT 11:30AM TO 1:30PM PM COUNT 4:00PM TO 6:00PM



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035

Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com

VEHICLE TURNING MOVEMENT COUNT

#003 15th St & California Avenue - AM PEAK

LOCATION#: 003
 NORTH / SOUTH: 15th St
 EAST / WEST: California Avenue

QTD PROJ#: 100158
 DATE: Thursday, September 23, 2010
 VICINITY: San Pablo, CA

DIRECTION:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	TOTALS
LANES:	0	0	0	0	1	0	0	1	0	0	1	0	
6:00 AM													
6:15 AM													
6:30 AM													
6:45 AM													
7:00 AM	0	0	0	0	0	2	0	2	0	0	1	0	5
7:15 AM	0	0	0	0	0	1	1	5	0	0	2	0	9
7:30 AM	0	0	0	0	0	0	0	4	0	0	5	2	11
7:45 AM	0	0	0	0	0	1	0	11	0	0	6	1	19
8:00 AM	0	0	0	3	0	2	2	21	0	0	12	2	42
8:15 AM	0	0	0	4	0	1	1	19	0	0	5	3	33
8:30 AM	0	0	0	3	0	2	0	6	0	0	14	6	31
8:45 AM	0	0	0	0	0	0	0	7	0	0	3	2	12
9:00 AM													
9:15 AM													
9:30 AM													
9:45 AM													
10:00 AM													
10:15 AM													
10:30 AM													

VOLUME STATS:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	
TOTAL:	0	0	0	10	0	9	4	75	0	0	48	16	162
P.H.V: ₁	0	0	0	10	0	6	3	57	0	0	37	12	125
P.H.F: ₂	_____	0.000	_____	_____	0.800	_____	_____	0.652	_____	_____	0.613	_____	0.744

- (1) Peak Hour Volume (Peak Hour Begins At 745 AM)
- (2) Peak Hour Factor (directional aggregate)



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035
 Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com

VEHICLE TURNING MOVEMENT COUNT

#003 15th St & California Avenue - MD PEAK

LOCATION#: 003
 NORTH / SOUTH: 15th St
 EAST / WEST: California Avenue

QTD PROJ#: 100158
 DATE: Thursday, September 23, 2010
 VICINITY: San Pablo, CA

DIRECTION:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	TOTALS
LANES:	0	0	0	0	1	0	0	1	0	0	1	0	
10:45 AM													
11:00 AM													
11:15 AM													
11:30 AM	0	0	0	0	0	2	4	4	0	0	4	0	14
11:45 AM	0	0	0	0	0	1	1	2	0	0	2	0	6
12:00 PM	0	0	0	2	0	0	0	7	0	0	4	0	13
12:15 PM	0	0	0	1	0	1	1	2	0	0	8	0	13
12:30 PM	0	0	0	0	0	3	2	3	0	0	6	1	15
12:45 PM	0	0	0	0	0	0	0	0	0	0	5	2	7
1:00 PM	0	0	0	2	0	0	0	5	0	0	4	1	12
1:15 PM	0	0	0	0	0	2	0	2	0	0	5	0	9
1:30 PM													
1:45 PM													
2:00 PM													
2:15 PM													
2:30 PM													
2:45 PM													
3:00 PM													
3:15 PM													
3:30 PM													
3:45 PM													

VOLUME STATS:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	
TOTAL:	0	0	0	5	0	9	8	25	0	0	38	4	89
P.H.V: ₁	0	0	0	3	0	4	3	12	0	0	23	3	48
P.H.F: ₂	_____	0.000	_____	_____	0.583	_____	_____	0.536	_____	_____	0.813	_____	0.800

(1) Peak Hour Volume (Peak Hour Begins At 1200 PM)

(2) Peak Hour Factor (directional aggregate)



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035

Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com

VEHICLE TURNING MOVEMENT COUNT

#003 15th St & California Avenue - PM PEAK

LOCATION#: 003
 NORTH / SOUTH: 15th St
 EAST / WEST: California Avenue

QTD PROJ#: 100158
 DATE: Thursday, September 23, 2010
 VICINITY: San Pablo, CA

DIRECTION:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	TOTALS
LANES:	0	0	0	0	1	0	0	1	0	0	1	0	
3:00 PM													
3:15 PM													
3:30 PM													
3:45 PM													
4:00 PM	0	0	0	1	0	4	0	7	0	0	4	0	16
4:15 PM	0	0	0	0	0	0	0	1	0	0	1	0	2
4:30 PM	0	0	0	1	0	0	0	3	0	0	0	0	4
4:45 PM	0	0	0	0	0	0	0	4	0	0	2	0	6
5:00 PM	0	0	0	1	0	3	0	7	0	0	4	1	16
5:15 PM	0	0	0	2	0	4	2	10	0	0	5	2	25
5:30 PM	0	0	0	1	0	1	1	4	0	0	6	1	14
5:45 PM	0	0	0	2	0	2	2	5	0	0	1	0	12
6:00 PM													
6:15 PM													
6:30 PM													
6:45 PM													

VOLUME STATS:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	
TOTAL:	0	0	0	8	0	14	5	41	0	0	23	4	95
P.H.V: ₁	0	0	0	6	0	10	5	26	0	0	16	4	67
P.H.F: ₂	_____	0.000	_____	_____	0.667	_____	_____	0.646	_____	_____	0.714	_____	0.670

- (1) Peak Hour Volume (Peak Hour Begins At 500 PM)
- (2) Peak Hour Factor (directional aggregate)



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035
 Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com